

CreaGlas PU Hardener 3472



Special hardener for CreaGlas 2K-PU Finish 3471

Field of application

For mixing with CreaGlas 2K-PU Finish 3471.

Properties

Special system hardener. The container sizes reflect the mixing ratio.

Material description

Color shade	yellowish
Base material	Aliphatic polyisocyanate
Flash point	> +61°C
Density	Approx. 1.1 g/cm ³
Packaging	800 g hardener for 5 kg of base material 2.4 kg hardener for 15 kg of base material (Base enamel and hardener are supplied separately)

Use

Mixing	Before adding the hardener, thoroughly stir the CreaGlas 2K-PU Finish 3471 until a homogeneous mass is obtained. Mix base component and hardener in the specified mixing ratio shortly before application. Ensure that the hardener container is completely emptied without residue. Follow the instructions in the CreaGlas 2K-PU Finish 3471 data sheet.
Compatibility	Can only be mixed with materials specified in this data sheet.
Application temperature	Do not apply at temperatures below +5°C or above a max. of +25°C air, substrate and material temperature.
Tool cleaning	Clean tools with water and wetting agent immediately after use.

Storage

Store in a cool, dry and frost-free place. Reseal opened containers tightly.

Declaration

Product code PU10
Comply with the specifications in the current safety data sheet.

Notes

Further information Follow the instructions in the data sheets of the products used.

Remark

This data sheet is based on extensive development work and years of practical experience. The translation corresponds to the current German version, in compliance with the German laws, regulations, standards and guidelines. Its content does not constitute a contractual legal relationship. The user/buyer is not released from the responsibility of checking our products to ensure they are suitable for the intended application. In addition, our general terms of business apply.

When a new version of this data sheet with updated information is published, the previous version no longer applies. The current version is available on our website.

Brillux
Weseler Straße 401
48163 Münster
GERMANY
Phone +49 251 7188-0
Fax +49 251 7188-105
info@brillux.de
www.brillux.com