

Universal Thinner 432



For thinning synthetic enamels

Field of application

For consistency regulation for improved application of synthetic enamels, e.g. MP Thick Film 229, with brush and roller. Also suitable for cleaning the required tools and for removing tough enamel soiling.

Properties

Intense-acting solvent, predominantly for thinning synthetic enamels.

Material description

Color shade	colorless
Base material	Solvent mixture based on hydrocarbons and esters.
VOC value	max. 880 g/l
Flash point	+47 °C
Density	approx. 0.871 g/cm ³
Packaging	500 ml, 1 l, 5 l and 30 l

Use

Add the relevant product in the specified mixing ratio depending on the individual requirements and mix thoroughly. Follow the more detailed instructions on the viscosity setting in the individual data sheets.

Storage

Store in a cool and dry location. Protect from direct sunlight.

Declaration

Product code M-VM04
Comply with the specifications in the current Safety Data Sheet.

Notes

Mask surfaces Carefully mask the surrounding area and particularly sensitive materials.

Further information Follow the instructions in the data sheets of the products used.

Remark

This Data Sheet is based on extensive development work and years of practical experience. The translation corresponds to the current German version, in compliance with the German laws, regulations, standards and guidelines. Its content does not constitute a contractual legal relationship. The user/buyer is not released from the responsibility of checking our products to ensure they are suitable for the intended application. In addition, our general terms of business apply.

When a new version of this Data Sheet with updated information is published, the previous version no longer applies. The current version is available on our website.

Brillux
Weseler Straße 401
48163 Münster
GERMANY
Phone +49 251 7188-0
Fax +49 251 7188-105
info@brillux.de
www.brillux.com